STATEMENT OF WORK
FOR THE
STANDARDIZED
BARE BASE
LAUNDRY FACILITY
NSN 3510-01-165-6845
Inspect Repair Only As Necessary
(IROAN)

TABLE OF CONTENTS

STATEMENT OF WORK FOR THE
STANDARDIZED BARE BASE LAUNDRY FACILITY
Inspect Repair Only As Necessary (IROAN)
NSN 3510-01-165-6845

1.0 SCOPE. This Statement of Work (SOW) establishes and sets forth tasks and identifies the work efforts that shall be performed by the Contractor in the IROAN effort of the **Standardized Bare Base Laundry Facility,** hereafter referred to as the **Laundry Unit**. This document contains requirements to restore the **Laundry Unit** to Condition Code "A." Condition Code A is defined as "serviceable/issuable without qualification, new, used, repaired or reconditioned materiel which is serviceable and issuable to all customers without limitation or restriction. Includes materiel with more than 6 months shelf-life remaining." National Stock Number **(NSN) 3510-01-165-6845** shall be known as the **Laundry Unit, Bare Base**.

1.1 Background. IROAN is defined as "That maintenance technique which determines the minimum repairs necessary to restore equipment components or assemblies to prescribed maintenance serviceability standards by utilizing all available diagnostic equipment and test procedures in order to minimize disassembly and parts replacement."

2.0 APPLICABLE DOCUMENTS. The following documents form a part of this SOW to the extent specified. Unless otherwise specified, the issues of these documents are those listed in the Department of Defense Index of Specifications and Standards (DoDISS) and supplement thereto which is in effect on the date of solicitation. In the event of conflict between the documents referenced herein and the contents of this SOW, the contents of this SOW shall be the superseding requirement.

2.1 Military Specifications

MIL-C-46168	Coating, Aliphatic Polyurethane, Chemical Agent Resistant
MIL-C-53039	Coating, Aliphatic Polyurethane, Single Component, Chemical Agent Resistant

2.2 Military Standards

MIL-STD-129	DoD Standard Practice for Military Marking
MIL-STD-130	Identification Marking of US. Military Property
MIL-STD-461	Requirements for the Control of Electromagnetic Interference Characteristics of Subsystems and Equipment
MIL-STD-2073-1D	DoD Standard Practice for Military Packaging

2.3 Other Government Documents and Publications

DOD 4160.21-M-1	Defense Demilitarization Manual
DOD 4000.25-1-M	MILSTRIP Manual
NAVICPINST 4491.2A	Requisitioning of Contractor Furnished Materiel From the Federal Supply System
SL-3-09950A	Field Laundry Unit
TM 09950A-14/1 M/S	Laundry Facility, Std Bare Base
TM 09950A-14/1 M/S, CH00A	Laundry Facility, Std Bare Base
TM 09950A-14/1 M/S, Supplement 1	Laundry Facility, Std Bare Base
TM 3080-12	Corroison Prevention and Control for Marine Corps Equipment
TM 3080-50	Corrosion Control Procedures Depot Maintenance Activities for Marine Corps Equipment
TM 4700-15/1H	Ground Equipment Record Procedures
TM 4750-15/1	Painting and Registration Marking for Marine Corps Combat and Tactical Equipment
TM 4750-15/2	Camouflage Paint Patterns
Military Handbooks (For Guidance)	
MIL-HDBK-61	Configuration Management Guidance

2.4 Industry Standards

ANSI/ISO/ASQC Q9002-1994	Quality Systems-Model for Quality Assurance in Production, Installation, and Servicing
Industry Standards (For Guidance)	
ANSI/EIA-649	National Consensus Standard for Configuration Management

Copies of military specifications and standards are available from the DOD Single Stock Point, Docment Automation and Production Service, Building 4/D, 700 Robbins Avenue, Philadelphia, PA 19111-5094, Telephone (215) 697-2179 or DSN 442-2179, or http://www.dodssp.daps.mil. Copies of other government documents and publications required by contractors in connection with

specific SOW requirements shall be obtained through the contracting officer: Commander, Marine Corps Logistics Bases, (Code 891) Attn: Contracting Officer, 814 Radford Blvd., Albany, Georgia 31704-1128, commercial telephone number (229) 639-6753 or DSN 567-6753. Copies of engineering drawings, if applicable, shall be obtained from Life Cycle Management Center, Attn; Code 851-3, 814 Radford Blvd STE 20320, Albany, Georgia 31704-0320, commercial telephone number (229) 639-6410 or DSN 567-6410.

3.0 REQUIREMENTS

3.1 General Tasks. In fulfilling the specified requirements, the Contractor shall:

a. Provide materials, labor, facilities, missing parts, and repair parts necessary to inspect, diagnose, restore, and test the **Laundry Unit**. Upon completion of IROAN, repaired equipment shall be Condition Code "A".

b. Provide all tools and test equipment required to test, inspect, repair, and calibrate the **Laundry Unit**.

c. Conduct in-process and final on-site testing for witness by an MCLB(Code 837-1), Albany, representative.

d. Be responsible for all structural, electrical and mechanical requirements associated with the restoration of the **Laundry Unit.**

3.2 Detail Tasks. The following tasks describe the different phases for IROAN of the **Laundry Unit**.

3.2.1 Phase I - Pre-induction. The Contracotr shall perform a pre-induction inspection analysis for each **Laundry Unit** using the Contractor's diagnosis, inspection and testing techniques to determine extent of work and parts required. This inspection shall include all items associated with the **Laundry Unit** as found in TM 09950A-14/1 M/S, TM 09950A-14/1 M/S CH00A, TM 09950A 14/1 M/S Supplement 1 and SL-3-09950A. These findings shall be annotated on a Pre-Induction Checklist (Appendix A-1) and shall be provided to the government in accordance with Paragraph 4.0 of this SOW.

3.2.2 Phase II - IROAN. After pre-induction tests and inspections have been completed, repair of the **Laundry Unit** shall be accomplished in accordance with this SOW. Deficiencies noted on the Pre-Induction Checklist during Phase I shall be repaired/replaced. Components or assemblies shall not be disassembled for replacement of mandatory parts unless that part has failed, or the component assembly wherein the part is located is disassembled for repair.

a. Pre-Induction Checklist - Information recorded on the Pre-Induction Checklist report shall be used as a guide to repair the **Laundry Unit** system in accordance with this SOW.

b. Technical Instruction (TI) - All TI's not previously applied to the **Laundry Unit** shall be applied during the IROAN and shall be annotated on Equipment Record Jacket in accordance with TM 4700-15/1H.

c. Corrosion - For corrosion prevention and treatment use TM 3080-12 and TM 3080-50.

d. Fluid Leaks - The following shall be used as a guide in determining degree of fluid loss:

(1) Class I - Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

(2) Class II - Leakage of fluid great enough to form drops, but not enough to cause drops to fall from the item being checked/inspected.

(3) Class III- Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

NOTE:

A Class I Leak, except in fuel or brake systems, is an acceptable condition at any time and does not require corrective action.

e. Belts - Replace all.

f. Data Plates - All required data plates and decals shall be in place and shall be legible. Each repaired **Laundry Unit** shall have an IROAN data plate affixed to the main unit in close proximity to the existing data plate. The data plate shall meet the requirements of MIL-STD-130 and TM 4750-15/2.

g. Painting/Coating (Exterior/Interior) - If painting/coating is required, refer to TM 4750-15/1 and TM 4750-15/2. The **Laundry Unit** shall be cleaned in accordance with TM 3080-50, Chapter 4, and coated with Aliphatic Polyurethane Coating, in accordance with MIL-C-46168 or MIL-C-53039.

h. Demilitarization - All end items that are identified as non-repairable and require demilitarization codes, shall be reported to the Marine Corps Logistics Bases representatives Code 837-1, who will provide disposition instructions in accordance with DOD 4160.21-M-1.

i. Electromagnetic Emission - All requirements pertaining to control of electromagnetic interference, emission and susceptibility shall be in accordance with MIL-STD-461.

j. Hardware

(1) Replace broken, unserviceable and/or missing hardware including nuts, bolts, screws, washers, turnlock fasteners, mandatory replacement items, safety, and one-time use items, etc., in accordance with TM 09950A-14/1 M/S and SL-3-09950A. Unserviceable would include any of the above that failed to function properly.

(2) Ensure proper hardware locking devices are present and operational on all moving mechanical assemblies.

(3) Hardware normally supplied with commercial parts shall be used unless specifically prohibited.

k. Hoses - All hoses and fittings shall be visually inspected for damage or deterioration. Any hose showing signs of leakage, kinking or separation of outer coating shall be replaced. This inspection shall be performed during the Pre-induction inspection of the **Laundry Unit**.

l.Cable Assemblies - All cables and cable connections shall be tested and visually inspected for damage or corrosion. Any cable or cable connector showing signs of damage, corrosion or separation of outer coating shall be repaired/replaced and tested with it's respective component/assembly to assure satisfactory compliance with all operational tests.

m. Filters - Replace all.

3.2.3 Phase III - Inspection, Testing and Acceptance

a. Inspection, Testing and Acceptance of the **Laundry Unit** shall be conducted in accordance with TM 09950A-14/1 M/S.

b. The Contractor shall be responsible for conducting required tests and shall ensure all necessary personnel are available to complete the final acceptance. Acceptance tests shall be held at the Contractor facility. MCLB (Code 837-1), Albany, Georgia, representatives shall be given a minimum of two weeks notice prior to beginning acceptance testing. The test area shall be cleared of all equipment parts, components, etc., not required for the test.

c. The Contractor shall be responsible for correcting any deficiencies identified during inspection/testing. MCLB (Code 837-1), Albany, Georgia, representatives may require the Contractor to repeat tests or portions thereof, if the original tests fail to demonstrate compliance with this SOW.

d. Acceptance testing on all **Laundry units** repaired under the provisions of this SOW shall be accomplished in accordance with TM 09950A-14/1 M/S. Operational Tests are to be conducted on each **Laundry Unit** upon completion of repairs and prior to the equipment being returned to stock, to insure the unit will perform as required.

3.2.4 Phase IV - Packaging, Handling, Storage, and Transportation (PHS&T).

a. The contractor shall be responsible for the preservation and packaging of items being repaired under the terms of this statement of work. Items scheduled for long term storage or shipment to overseas destinations shall be in accordance with the Level "A" requirements of MIL-STD-2073-1D, Method 10. Items being scheduled for domestic shipment, immediate use or short-term storage shall be to Level "B" requirements.

b. Marking shall be in accordance with MIL-STD-129.

c. The Marine Corps will provide the contractor with the shipping address(es) for delivery of the repaired equipment. The contractor shall be responsible for arranging for shipment to the pre-

designated site(s). The Marine Corps will be responsible for the transportation costs associated with shipping the subject equipment to and from the Contractor.

3.3 Configuration Management

3.3.1 Configuration Status Accounting (CSA).

a. The Contractor shall record and submit data on retrofit accomplished during Phase II. Any approved Modification Instructions (MIs) or Engineering Change Proposals (ECP's) not previously applied shall be applied during Phase II of the IROAN process.

b. The Contractor shall determine the application status of approved configuration changes by visual inspections to the extent possible. The government will identify the configuration changes to be inspected by furnishing a Configuration Inspection Checklist to the Contractor. The Contractor shall use one checklist per **Laundry Unit** to record their inspection findings along with other required data.

c. The Contractor shall record serial numbers of the assemblies listed on the Configuration Inspection Checklist. The Contractor shall record the information on the same form that was used to record the application status of configuration changes.

3.3.2 Configuration Control. The contractor shall apply configuration control procedures to established configuration items. The contractor shall not implement configuration changes to an item's documented performance or design characteristics without prior written authorization. If it is necessary to temporarily depart from the authorized configuration, the contractor shall prepare and submit a Request For Deviation. MIL-HDBK-61 (paragraph 4.3 and Table 4-9) and ANSI/EIA-649 (paragraph 5.3.4) provide guidance for preparing this configuration control document.

3.4 Quality Assurance Provisions. The Contractor shall provide and maintain a Quality System that as a minimum, adheres to the requirements of ANSI/ISO/ASQC Q9002-1994, Quality System Model for Quality Assurance in Production, Installation, and Servicing. The program shall ensure quality throughout all areas to include processing, assembly, inspection, test, maintenance, and preparation for delivery and shipping. Unless otherwise specified in the contract, the Contractor shall be responsible for performance of all inspection requirements. The Government MCLBA (Code 837-1) reserves the right to perform any of the inspections set forth in the contract where such inspections are deemed necessary to assure products and services conform to the prescribed requirements. The Contractor shall provide an Inspection and Test Plan.

3.5 Government Furnished Equipment (GFE)/Government Furnished Materiel (GFM). GFE is government owned equipment authorized by contract for use by a Commercial/Goverment contractor. It is neither consumed during production nor incorporated into any product. GFM is materiel furnished to a contractor that will be consumed during the course of production or incorporated into product being manufactured/remanufactured under a contract/statement of work. In the event the Marine Corps does have GFE/GFM requirements the Management Control Activity (MCA/Code 827-2), Marine Corps Logistics Bases, Albany, Georgia, will coordinate required GFE and will maintain a central control on Marine Corps assets in Contractor's possession. The MCA

will forward a GFE Accountability agreement to the Contractor Facility for signature to establish a chain of custody and property responsibilities for Marine Corps assets.

3.6 Contractor Furnished Materiel (CFM). The Marine Corps has adopted the Navy's procedures regarding Contractor Furnished Materiel (NAVICPINST 4491.2A). In the event that Contractor Furnished Materiel is required for repair parts, the contractor shall requisition through the DoD Supply System. DOD 4000.25-1-M,(MILSTRIP) Chapter 11 authorizes contractors to requisition through the DoD Supply System.

3.7 Acceptance. The performance of the Contractor and the quality of work delivered, including all equipment furnished and documentation written or compiled, shall be subject to in-process review and inspection during performance. Inspection may be accomplished in-plant or at any work site or location, and Marine Corps representatives (Code 837-1) shall be permitted to observe the work or to conduct inspection at all reasonable hours. Final inspection and acceptance testing shall be conducted at the Contractor. Final acceptance shall be conducted on 100 percent of items to verify that the units meet all requirements.

3.8 Rejection. Failure to comply with any of the specified requirements listed herein shall be reason for rejection by MCLB (Code 837-1), Albany, representative. The Contractor shall, at no additional cost to MCLB, Albany, Georgia, provide the following:

a. Develop an approach for modification or correction of all deficiencies.

b. Upon approval of a documented approach, the Contractor shall correct the deficiencies and repeat the verification until an acceptable compliance with acceptance test procedures is demonstrated.

4.0 REPORTS. All report deliverables shall be submitted in hard copy to Commander (Code 837-1), Marine Corps Logistics Bases, 814 Radford Blvd., Suite 20320, Albany, Georgia 31704-0320, unless directed other wise in a Contract Data Requirements List.

4.1 Repairable Item Inspection Report. The Contractor shall provide a Repairable Item Inspection Report for each **Laundry Unit.** The report shall be identified by United States Marine Corps Serial Number.

4.2 Monthly Progress Reports. The Contractor shall provide Monthly Progress Reports summarizing the progress and status of the IROAN Program.

4.3 Pre-Induction Checklist. The Contractor shall complete the Pre-Induction Inspection Checklist for each **Laundry Unit** repaired. These documents shall be available during final acceptance testing. One copy of each document shall be provided to MCLB, Albany, Georgia, Code 837-1, after final acceptance of the **Laundry Unit**.

a. The inspection checklist shall contain, but not be limited to the following:

(1) **Laundry Unit** serial number. Appendix A-1
(2) Condition Code of **Laundry Unit** at receipt. Appendix A-1

(3) Results of operational test. Appendix A-1
(4) List of defective parts and assemblies. Appendix B-1
(5) List of repair parts and assemblies required for repairs. Appendix C-1
(6) Corrosion prevention methods that shall be used. Appendix A-1

Serial number:_____ Condition Code at receipt: _____
Results of operational test:

_____
_____
_____
_____
_____
_____
_____
_____
_____
_____
_____
_____
List of defective parts and assemblies. Appendix B
List of repair parts and assemblies required for repairs. Appendix C
Corrosion prevention methods that shall be used.

_____
_____
_____
_____
_____
_____
_____
_____
_____
__

Inspect all components for operating/malfunction/defective parts per TM 09950A-14/1 M/S. Visually check components for leaks, damage, loose parts & hardware. No disassembly of components is allowed unless the component is determined to be defective.

COMPONENTS:	PASS	FAIL	REMARKS:
LAUNDRY FACILITY BARE BASE	_____	_____	_____
MAIN PLATFORM ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-2)	_____	_____	_____
STORAGE BIN ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-3)	_____	_____	_____
LAUNDRY WASHER ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-4)	_____	_____	_____
LAUNDRY WASHER ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-7)	_____	_____	_____
CLAMP ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-13)	_____	_____	_____
COUPLINGS	_____	_____	_____
COUPLING HALF, QUICK	_____	_____	_____
DISCONNECT,	_____	_____	_____
CAM-LOCKINC ALL ENDS	_____	_____	_____
PLUG, SQ HD,	_____	_____	_____
ELBOW, ST BRASS	_____	_____	_____
BUSHING, BRASS,	_____	_____	_____
COMPRESSOR UNIT,	_____	_____	_____
RECIPROCATING,	_____	_____	_____
(SEE FIGURE 7-14)	_____	_____	_____
CONTROLLER AND	_____	_____	_____
			_____
			_____

COMPONENTS	PASS	FAIL	REMARKS
ELECTRICAL PANEL,	____	____	
(SEE FIGURE 7-16)	____	____	
WATER HEATER,	____	____	
(SEE FIGURE 7-22)	____	____	
HEATER FUEL LINE ASSEMBLY,	____	____	
(SEE FIGURE 7-23)	____	____	
HEATER TIEDOWN ASSEMBLY,	____	____	
(SEE FIGURE 7-24)	____	____	
LAUNDRY EXTRACTOR,	____	____	
(SEE FIGURE 7-25)	____	____	
TIE DOWN CLIP ASSEMBLY,	____	____	
(SEE FIGURE 7-30)	____	____	
WATER PUMP ASSEMBLY,	____	____	
(SEE FIGURE 7-31)	____	____	
HOSE CONNECT ASSEMBLY,	____	____	
(SEE FIGURE 7-32)	____	____	
PUMP TIEDOWN ASSEMBLY,	____	____	
(SEE FIGURE 7-33)	____	—	
DRYER ASSEMBLY,	____	____	
(SEE FIGURE 7-34)	____	____	
DRYER FUEL LINE ASSEMBLY,	____	____	
(SEE FIGURE 7-23)	____	____	
EXHAUST HOSE	____	____	
TIEDOWN ASSEMBLY,	____	____	
(SEE FIGURE 7-45)	____	____	
EXHAUST HOSE	____	____	
TIEDOWN ASSEMBLY,	____	____	
(SEF, FIGURE 7-46)	—	____	
CONDUIT ASSEMBLY,	____	____	
(SEE FIGURE 7-47)	____	____	
RAIL, SIDE,84 IN LG	____	____	
CLOTHES BIN ASSEMBLY,	____	____	
(SEF, FIGURE 7-48)	____	____	
POWER CABLE ASSEMBLY,	____	____	
(SEE FIGURE, 7-49)	____	____	
SPACER	____	____	
COVER ASSEMBLY RED 1, 2, & 3	____	____	
MAIN PLATFORM ASSEMBLY	____	____	
PLATFORM, LEFT ASSEMBLY	____	____	
PLATFORM, FRAME ASSEMBLY	____	____	
DECK, LARGE TOP ASSEMBLY	____	____	
DECK, SMALL TOP ASSEMBLY	____	____	
DECK, LARGE BOTTOM	____	____	
ASSEMBLY	____	____	
DECK, SMALL BOTTOM	____	____	
ASSEMBLY	____	____	
RAIL	____	____	
RAIL, SIDE	____	____	
SLEEVE	____	____	
STRAP, RETAINING,	____	____	

COMPONENTS	PASS	FAIL	REMARKS
PLATFORM, RIGHT ASSEMBLY	____	____	
JOINING PANEL ASSEMBLY	____	____	
STORAGE BIN ASSEMBLY	____	____	
BIN, LARGE	____	____	
PLATFORM	____	____	
BIN, SMALL	____	____	
COVER ASSEMBLY	____	____	
FASTENER, LINK LOCK	____	____	
TRAY	____	____	
LAUNDRY WASHER	____	____	
WASHER ASSEMBLY,	____	____	
(SEE FIGURE 7-5)	____	____	
PLATE, TANK MOUNTING	____	____	
ELBOW, PIPE,	____	____	
TEE, PIPE, STL,	____	____	
COCK, DRAIN,	____	____	
WASHER ASSEMBLY, OPEN END	____	____	
COVER, BASE SIDE LEFT	____	____	
COVER, BASE FRONT	____	____	
COVER, BASE SIDE RIGHT	____	____	
SUPPLY INJECTOR ASSEMBLY	____	____	
SHELL ASSEMBLY	____	____	
SHELL FRONT ASSEMBLY	____	____	
SHELL, EXTRUSION	____	____	
RING, SHELL	____	____	
PLATE, MOUNTING	____	____	
MICROSWITCH	____	____	
CAM, DOOR	____	____	
HANDLE ASSEMBLY,	____	____	
DOOR, ASSEMBLY	____	____	
BRACKET, HINGE	____	____	
CYLINDER ASSEMBLY	____	____	
HOUSING, SHAFT SEAL	____	____	
GASKET, SHAFT SEAL	____	____	
SEAL, PLAIN, STL,	____	____	
COVER, SHAFT RETAINER	____	____	
SPACER, SHAFT RETAINER	____	____	
KEY, MACHINE, STL	____	____	
SPIDER,	____	____	
GEAR ASSEMBLY,	____	____	
SPEED DECREASER	____	____	
MOTOR, ALTERNATING	____	____	
MOUNT, MOTOR	____	____	
BRACKET, MOTOR MOUNT, LEFT	____	____	
BRACKET, MOTOR MOUNT, RIGHT	____	____	
BELT GUARD ASSEMBLY	____	____	
BRACKET, BELT UPPER	____	____	
BELT, V, RBR,	____	____	
BRACKET, BELT, LOWER LEFT	____	____	
PULLEY, GROOVE,	____	____	

COMPONENTS	PASS	FAIL	REMARKS
BUSHING, SLEEVE	____	____	
V-PULLEY	____	____	
BUSHING, SLEEVE	____	____	
COVER, SYPHON	____	____	
BREAKER	____	____	
PIPE, ELBOW	____	____	
WATER LEVEL FLOAT,	____	____	
CHAMBER ASSEMBLY,	_	____	
(SEE FIC3URE 7-6)	____	____	
SOAP CHUTE	____	____	
COVER, SOAP CHUTE	____	____	
HINGE, SOAP CHUTE	____	____	
ROD, SOAP CHUTE	____	____	
PIPE, METALLIC	____	____	
HOSE, NONMETALLIC,	____	____	
PIPE, WATER INLET	____	____	
VALVE, ANGLE,	____	____	
WATER LEVEL FLOAT	____	____	
CHAMBER ASSEMBLY	____	____	
SWITCH, LIQUID LEVEL	____	____	
TUBING, GLASS,	—	____	
CLAMP, LOOP	____	____	
BRACKET, LEVEL CONTROL	____	____	
BRACKET, TOP FLOAT	____	____	
CHAMBER	____	____	
BRACKET, BOTTOM	____	____	
FLOAT CHAMBER	____	____	
FLOAT ASSEMBLY,	____	____	
LIQUID LEVEL	____	____	
FLOAT	____	____	
ROD,FLOAT,	____	____	
SPFED NUT	____	____	
LAUNDRY WASHER ASSEMBLY	____	____	
FRAME ASSEMBLY	____	____	
DOOR ASSEMBLY,	____	____	
(SEE FIGURE 7-8)	____	____	
DOOR LOCK ASSEMBLY,	____	____	
(SEE FIGURE 7-9)	____	____	
DRAW BAND, WASHER	____	____	
EXTRACTOR	____	____	
GASKET, RBR CHLOROPRENE	____	____	
DRUM FRONT	____	____	
CYLINDER ASSEMBLY	____	____	
SPIDER AND SHAFT ASSEMBLY	____	____	
ROD, THREADED END	____	____	
RING, GASKET CLAMP	____	____	
GASKET, SOCK	____	____	
MOTOR	____	____	
PLATE, MOTOR MOUNTING	____	____	
ROD, MOTOR ADJUSTING	____	____	

COMPONENTS	PASS	FAIL	REMARKS
BELT	____	____	_____
PULLFY, GROOVE,	____	____	_____
BUSHING, SHEAVE	____	____	_____
DRUM ASSEMBLY	____	____	_____
WATER INLET ASSEMBLY,	____	____	_____
(SEE FIGURE 7-10)	____	____	_____
SHEAVE	____	____	_____
BUSHING, SHEAVE	____	____	_____
GEAR ASSEMBLY,	____	____	_____
PLATE, MOUNTING	____	____	_____
SEAL AND CARRIAGE ASSEMBLY,	____	____	_____
SEAL, PLAIN	____	____	_____
DISPENSER ASSEMBLY,	____	____	_____
(SEE FIGURE 7-11)	____	____	_____
GAUGE,TEMPERATURE	____	____	_____
BOTTLE, SUPPLY	____	____	_____
VALVE ASSEMBLY,DRAIN,	____	____	_____
(SEE FIGURE 7-12)	____	____	_____
PLUG, PIPE	____	____	_____
HOSE, DRAIN	____	____	_____
DOOR ASSEMBLY	____	____	_____
DOOR HINGE AND	____	____	_____
HANDLE	____	____	_____
BASE, DOOR HINGE	____	____	_____
BUSHING, FLANGE,	____	____	_____
PIN, DOOR HINGE	____	____	_____
BEARING, WASHER,	____	____	_____
BAR, DOOR	____	____	_____
FASTENER, PAWL	____	____	_____
BOLT, PIVOT	____	____	_____
BUSHING, SLEEVE	____	____	_____
RING, RETAINING	____	____	_____
WINDOW, OBSERVATION, GLASS,	____	____	_____
GASKET, DOOR GLASS	____	____	_____
FRAME, DOOR	____	____	_____
DRAW BAND, DOOR	____	____	_____
GASKET, DRAW BAND	____	____	_____
GASKET, DOOR	____	____	_____
DOOR LOCK ASSEMBLY	____	____	_____
DOOR LOCK COVER AND SWITCH	____	____	_____
COVER, DOOR LOCK	____	____	_____
SWITCH, PUSH	____	____	_____
BOOT, DUST AND MOISTURE SEAL	____	____	_____
BRACKET, MOUNTING	____	____	_____
BUSHING, ELECTRICAL	____	____	_____
CONDUCTOR,	____	____	_____
SOLENOID,	____	____	_____
SWITCH,	____	____	_____
PLATE, DOOR LOCK	____	____	_____
SPRING, DOOR LOCK	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
BAR, DOOR LOCK	____	____	_____
SPRING, DOOR LATCH	____	____	_____
WATER INLET ASSEMBLY	____	____	_____
LEVER, MANUAL CONTROL	____	____	_____
CLEVIS, ROD END,	____	____	_____
CYLINDER ASSEMBLY,	____	____	_____
ROD, ADJUSTINC STUD	____	____	_____
BRACKET, MOUNTING	____	____	_____
COUPLER, FEMALE	____	____	_____
COUPLING HALF,QUICK	____	____	_____
DISCONNECT,	____	____	_____
ELBOW, PIPE,	____	____	_____
NIPPLE, PIPE,	____	____	_____
PIPE, METALLIC,	____	____	_____
ELBOW, PIPE TO HOSE,	____	____	_____
ELBOW, PIPE,	____	____	_____
BUSHING, PIPE	____	____	_____
TEE, PIPE	____	____	_____
VALVE, BALL,	____	____	_____
NIPPLE, PIPE,	____	____	_____
DISPENSER ASSEMBLY	____	____	_____
DISPENSER	____	____	_____
COVER	____	____	_____
HOSE, SUPPLY1	____	____	_____
SUPPLY HOSE, AIR	____	____	_____
HOSE, SUPPLY 2	____	____	_____
HOSE, SUPPLY 3	____	____	_____
HOSE, SUPPLY 4	____	____	_____
FITTING, HOSE	____	____	_____
COUPLING, PIPE,	____	____	_____
HOSE, SUPPLY INLET	____	____	_____
ADAPTER, STRAIGHT	____	____	_____
VALVE, SOLENOID,	____	____	_____
MANIFOLD, SUPPLY	____	____	_____
BRACKET, MANIFOLD	____	____	_____
MOUNTING	____	____	_____
DRAIN VALVE ASSEMBLY	____	____	_____
PLATE,TOP	____	____	_____
BELLOWS, RUBBER,	____	____	_____
ADAPTER, STRAIGHT,	____	____	_____
PLATE, MOUNTING	____	____	_____
BRACKET	____	____	_____
HOSE, NONMETALLIC,	____	____	_____
PINCH TUBE	____	____	_____
CLAMP ASSEMBLY	____	____	_____
ANGLE	____	____	_____
ROD,THREADED, SHORT	____	____	_____
RING, HANGER	____	____	_____
AIR COMPRESSOR ASSEMBLY	____	____	_____
GRILLE, METAL	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
HANDLE, DOOR, L STYLE	____	____	_____
KIT, SWITCH, (SEE FIGURE 7-15)	____	____	_____
HOUSING, AIR COMPRESSOR	____	____	_____
CYLINDER, HEAD ASSEMBLY,	____	____	_____
RIGHT HAND	____	____	_____
CYLINDER HEAD ASSEMBLY,	____	____	_____
LEFT HAND	____	____	_____
MOTOR, ALTERNATING	____	____	_____
CABLE ASSEMBLY,	____	____	_____
PRESSURE SWITCH ASSEMBLY	____	____	_____
SWITCH, PRESSURE	____	____	_____
PLUG, BUTTON	____	____	_____
WIRE ASSEMBLY, BLK	____	____	_____
WIRE ASSEMBLY, WHT	____	____	_____
CONTROLLER AND	____	____	_____
ELECTRICAL PANEL SUPPORT	____	____	_____
FRAME ASSEMBLY	____	____	_____
FACE PLATE, LAUNDRY,	____	____	_____
COVER, CONTROLLER	____	____	_____
CONTROLLER ASSEMBLY	____	____	_____
HEAD ASSEMBLY,	____	____	_____
CONTROL BOX, (SEE FIGURE 7-17)	____	____	_____
CONTROL BOX ASSEMBLY,	____	____	_____
(SEE FIGURE 7-18)	____	____	_____
CONTROL CHASIS	____	____	_____
ASSEMBLY, LAUNDRY,	____	____	_____
(SEE FIGURE 7-19)	____	____	_____
HOSE, LOW PRESSURE	____	____	_____
ADAPTER, STRAIGHT	____	____	_____
SLEEVE	____	____	_____
FIRE EXTINGUISHER	____	____	_____
PLATE, MOUNTING	____	____	_____
STAND, CONTROLLER SUPPORT	____	____	_____
LOAD CENTER	____	____	_____
ENCLOSURE	____	____	_____
BRACKET, INTERIOR MOUNT	____	____	_____
KIT, INTERIOR TRIM	____	____	_____
CAP, END SEAL	____	____	_____
MAIN BREAKER, 30 AMP	____	____	_____
CIRCUIT BREAKER, 20 AMP	____	____	_____
BOX, 3 GANG	____	____	_____
GASKET, SYNTH-RBR,	____	____	_____
CONNECTOR, RECEPTACLE	____	____	_____
OUTLET	____	____	_____
COVER, CONDUIT	____	____	_____
COVER, LIFT	____	____	_____
SWITCH, MOTOR STARTING	____	____	_____
HEAD ASSEMBLY	____	____	_____
WINDOW, OBSERVATION,	____	____	_____
LATCH, SPECIAL	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
LAMP, 28V	____	____	_____
SOCKET, LAMP	____	____	_____
NAME PLATE	____	____	_____
WARNING	____	____	_____
NAME PLATE,	____	____	_____
TUBING,	____	____	_____
TYRAP,	____	____	_____
BRACKET, RECEPTACLE	____	____	_____
RECEPTACLE	____	____	_____
ANGLE, CENTER	____	____	_____
DOOR ASSEMBLY, PLASTIC	____	____	_____
WET PART, LAUNDRY	____	____	_____
PARTITION, SWITCH	____	____	_____
SKIRT, TIMING, LAUNDRY	____	____	_____
REAR ASSEMBLY	____	____	_____
BACK	____	____	_____
POWER SUPPLY	____	____	_____
VALVE, SOLENOID,	____	____	_____
STRAINER, SEDIMENT,	____	____	_____
NIPPLE, PIPE,	____	____	_____
ANGLE	____	____	_____
PLUG, PIPE	____	____	_____
BLOCK, MANIFOLD,	____	____	_____
CONTROL CHASIS ASSEMBLY	____	____	_____
CONTROL PANEL ASSEMBLY,	____	____	_____
(SEE FIGURE 7-20)	____	____	_____
FUSE, CARTRIDGE,	____	____	_____
FUSEHOLDER,	____	____	_____
VALVE, SOLENOID,	____	____	_____
VALVE, AIR CONTROL, 3 WAY	____	____	_____
RELAY, 3PDT, IO AMP	____	____	_____
SWITCH, PRESSURE	____	____	_____
RELAY,	____	____	_____
TIMING MOVEMENT,	____	____	_____
MECHANICAL,	____	____	_____
(SEE FIGURE 7-21)	____	____	_____
CONTROL PANEL ASSEMBLY	____	____	_____
PANEL,CONTROL	____	____	_____
TIMER, SEQUENTIAL	____	____	_____
SWITCH, TOGGLE,	____	____	_____
COVER, SWITCH	____	____	_____
REVERSING TIMER ASSEMBLY	____	____	_____
SHAFT, SHOULDERED,	____	____	_____
SWITCH, SENSITIVE,	____	____	_____
ADAPTER, SWITCH	____	____	_____
CAM, CONTROL	____	____	_____
SETSCREW,	____	____	_____
BRACKET, TIMER	____	____	_____
LAUNDRY EXTRACTOR	____	____	_____
ASSEMBLY	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
EXTRACTOR, BOCK MOISTRITE	____	____	_____
AND SPEEDRY	____	____	_____
MOTOR ASSEMBLY,	____	____	_____
(SEE FIGURE 7-26)	____	____	_____
MOTOR ASSEMBLY,	____	____	_____
(SEE FIGURE 7-27)	____	____	_____
SHEAVE, PULLEY	____	____	_____
V-BELT	____	____	_____
LID	____	____	_____
FRAME, LID HINCE	____	____	_____
BASKET BALL	____	____	_____
LID GASKET	____	____	_____
CURB ASSEMBLY	____	____	_____
WASHER, LEAD	____	____	_____
RUBBER WASHER	____	____	_____
HOSE,	____	____	_____
BASKET ASSEMBLY	____	____	_____
POST,CENTER	____	____	_____
SEAL,	____	____	_____
CENTER UNIT ASSEMBLY,	____	____	_____
(SEE FIGURE 7-28)	____	____	_____
HUB, BRAKE	____	____	_____
BACK PANEL ASSEMBLY,	____	____	_____
(SEE FIGURE 7,29)	____	____	_____
BASE ASSEMBLY	____	____	_____
TRUNNION FRAME, ASSEMBLY	____	____	_____
COUPLING HALF,	____	____	_____
MOTOR ASSEMBLY #1	____	____	_____
MOTOR, 3 HP	____	____	_____
SWITCH,	____	____	_____
MOUNT, SWITCH	____	____	_____
COUPLING	____	____	_____
HUB, BODY,	____	____	_____
PLATE, MOTOR MOUNT	____	____	_____
MOTOR ASSEMBLY #2	____	____	_____
MOTOR	____	____	_____
HUB, PULLEY	____	____	_____
PLATE, MOTOR MOUNT	____	____	_____
CENTER UNIT ASSEMBLY	____	____	_____
PIN, STUD	____	____	_____
ARM,BRAKE	____	____	_____
ARM, OPERATING	____	____	_____
BRACKET	____	____	_____
SPRING, HELICAL, EXTENSION	____	____	_____
BRAKE SHOE,	____	____	_____
COVER, TOP END	____	____	_____
SHIELD, SOLENOID	____	____	_____
ROD, SOLENOID	____	____	_____
SOLENOID, BRAKE	____	____	_____
HUB	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
BALL,BASKET	____	____	_____
INSERT, NYLON	____	____	_____
PACKING,	____	____	_____
CAP, BUMPER	____	____	_____
BUMPER RUBBERS	____	____	_____
CAP, TRUNNION	____	____	_____
RUBBER, TRUNNION	____	____	_____
HUB, PULLEY	____	____	_____
SHEAVES, PULLEY	____	____	_____
BACK PANEL ASSEMBLY	____	____	_____
BUTT0N, START	____	____	_____
SWITCH, PUSH-PULL,	____	____	_____
BUTTON, RED	____	____	_____
LIGHT, INDICATOR	____	____	_____
MICROSWITCH	____	____	_____
SOLENOID,	____	____	_____
RELAY,ELECTRO MAGNETIC	____	____	_____
TIMER,	____	____	_____
FUSE HOLDER	____	____	_____
FUSE, CARTRIDGE,	____	____	_____
TERMINAL BOARD	____	____	_____
COVER	____	____	_____
PLATE, BOTTOM	____	____	_____
BACK AND SIDES, CONTROL	____	____	_____
PANEL	____	____	_____
PLATE, MOUNT	____	____	_____
PLATE,TOP	____	____	_____
TIE DOWN CLIP ASSEMBLY	____	____	_____
BAR, TIE DOWN CLIP	____	____	_____
LEG, TIE DOWN CLIP	____	____	_____
PLATFORMS	____	____	_____
WATER PUMP ASSEMBLY	____	____	_____
WATER PUMP ASSEMBLY	____	____	_____
FRAME, AL-ALY	____	____	_____
SWITCH BOX ASSEMBLY	____	____	_____
COVERS	____	____	_____
COVER,BOX,FRONT	____	____	_____
PUMP UNIT	____	____	_____
BRACKET	____	____	_____
MOTOR, ALTERNATING	____	____	_____
CAP,	____	____	_____
COUPLING HALF,	____	____	_____
NIPPLE, PIPE	____	____	_____
HOSE CONNECTION ASSEMBLY	____	____	_____
SUCTION STRAINER ASSEMBLY	____	____	_____
COUPLING, QUICK DISCONNECT	____	____	_____
SUCTION HOSE ASSEMBLY	____	____	_____
COUPLING, HALF	____	____	_____
HEATER INTAKE HOSE ASSEMBLY	____	____	_____
WASHER, INTAKE HOSE	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
ASSEMBLY	____	____	_____
HOSES, WATER,	____	____	_____
CLOTHES BIN DISCHARGE HOSE	____	____	_____
EXTRACTOR DISCHARGE HOSE	____	____	_____
ASSEMBLY	____	____	_____
PUMP TIE DOWN ASSEMBLY	____	____	_____
CATCH, FIXED ASSEMBLY	____	____	_____
CATCH, ADJUSTABLE	____	____	_____
PLATFORM ASSEMBLY	____	____	_____
DRYER ASSEMBLY	____	____	_____
BLOWER ASSEMBLY,	____	____	_____
(SEE FIGURE 7-35)	____	____	_____
HOSE ASSEMBLIES	____	____	_____
BURNER TUMBLER ASSEMBLY,	____	____	_____
(SEE FIGURE 7-36)	____	____	_____
SWITCHES, SENSITIVE	____	____	_____
COVER	____	____	_____
LIGHT, INDICATOR,	____	____	_____
ALARM,BUZZER	____	____	_____
BUZZER,	____	____	_____
DOOR ASSEMBLY	____	____	_____
CHAIN, WELDLESS	____	____	_____
TIMER, SEQUENTIAL	____	____	_____
PLATE, INDENT	____	____	_____
LABEL, CAUTION	____	____	_____
LABEL, WARNING	____	____	_____
ARROW	____	____	_____
HANDLE, DOOR	____	____	_____
RING ASSEMBLY	____	____	_____
FRONT SHELL ASSEMBLY,	____	____	_____
(SEE FIGURE 7-39)	____	____	_____
HEATER TUMBLER ASSEMBLY,	____	____	_____
(SEE FIGURE 7-40)	____	____	_____
HOSE, AIR DUCT,	____	____	_____
HOSE, FLEX	____	____	_____
EXHAUST HOSE ADAPTER	____	____	_____
ASSEMBLY	____	____	_____
DUCT, HOSE,	____	____	_____
REDUCER, PIPE,	____	____	_____
ELBOW, AIR CONDITIONING	____	____	_____
HEATING	____	____	_____
PIN ASSEMBLY	____	____	_____
PIN	____	____	_____
CHAIN, SAFETY	____	____	_____
HOOK, CHAIN,	____	____	_____
THERMOMETER	____	____	_____
DISCHARGE SPOUT ASSEMBLY	____	____	_____
COUPLING, HALF	____	____	_____
CONTROL, TEMPERATURE, DIAL	____	____	_____
AND KNOB	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
CONNECTOR, ELBOW,	____	____	_____
BOX CONNECTOR,	____	____	_____
FAN ASSEMBLY, (SEE FIGURE 7-41)	____	____	_____
COVER	____	____	_____
CONTROL PANEL ASSEMBLY,	____	____	_____
(SEE FIGURE 7-42)	____	____	_____
TUMBLER SPEED REDUCER ASSEMBLY,	____	____	_____
(SEE FIGURE 7-43)	____	____	_____
ROD, THREADED	____	____	_____
CUP, GREASE,	____	____	_____
CUP OIL,	____	____	_____
PLATES, RETAINING,	____	____	_____
GUARD	____	____	_____
CHAIN, STL, 65 LINKS	____	____	_____
WIRE, SAFETY	____	____	_____
TUMBLER ASSEMBLY,	____	____	_____
(SEE, FIGURE 7-44)	____	____	_____
SHELL ASSEMBLY	____	____	_____
TUMBLER BASE ASSEMBLY	____	____	_____
PANEL, SIDE	____	____	_____
INSULATOR,PLATE,	____	____	_____
STRIP	____	____	_____
BLOWER ASSEMBLY	____	____	_____
GUAGE, PRESSURE	____	____	_____
COCK, DRAIN	____	____	_____
TEE	____	____	_____
NIPPLE	____	____	_____
PUMP, FUEL	____	____	_____
SHUTTER ASSEMBLY,	____	____	_____
HOUSING	____	____	_____
HOUSING, BLOWER	____	____	_____
WHEEL, BLOWER	____	____	_____
MOUNT, BLOWER	____	____	_____
KEY	____	____	_____
MOTOR, ALTERNATING	____	____	_____
BURNER TUMBLER ASSEMBLY	____	____	_____
CAP FITTING	____	____	_____
GASKET, PEEP SIGHT,	____	____	_____
GLASS, PEEP HOLE	____	____	_____
NIPPLE	____	____	_____
COVER	____	____	_____
CABLE AND TERMINAL ASSEMBLY,	____	____	_____
(SEE FIGURE 7-37)	____	____	_____
ELECTRODE ASSEMBLY,	____	____	_____
(SEE FIGURE 7-38)	____	____	_____
BRACKET, TRANSFORMER	____	____	_____
TRANSFORMER	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
BOX, JUNCTION	____	____	_____
COVER	____	____	_____
BOX CONNECTORS,	____	____	_____
CONNECTOR, STRAIGHT	____	____	_____
AIR PLENUM	____	____	_____
CABLE AND TERMINAL	____	____	_____
ASSEMBLY	____	____	_____
CABLE	____	____	_____
TERMINAL, LUG,	____	____	_____
ELECTRODE ASSEMBLY	____	____	_____
ELECTRODE	____	____	_____
NOZZLE ASSEMBLY	____	____	_____
NOZZLE	____	____	_____
PIPE	____	____	_____
BASE, BURNER	____	____	_____
FRONT SHELL ASSEMBLY	____	____	_____
DOOR	____	____	_____
HINGE ASSEMBLY	____	____	_____
HINGE	____	____	_____
PIN, SPRING	____	____	_____
FRONT, SHELL	____	____	_____
HEATER TUMBLER ASSEMBLY	____	____	_____
SCREEN ASSEMBLY,	____	____	_____
PANEL, COVER	____	____	_____
HOOD ASSEMBLY	____	____	_____
HOOD	____	____	_____
PLATE	____	____	_____
COVER, FRONT	____	____	_____
COVER, REAR	____	____	_____
BURNER MOUNTING ASSEMBLY	____	____	_____
RETURN BOX NO 5 ASSEMBLY	____	____	_____
COVER, ASSEMBLY	____	____	_____
RETURN BOX NO 3 ASSEMBLY	____	____	_____
RETURN BOX NO 1 ASSEMBLY	____	____	_____
RETURN BOX NO 4 ASSEMBLY	____	____	_____
RETURN BOX NO 2 ASSEMBLY	____	____	_____
MOUNTING PLATE ASSEMBLY	____	____	_____
FAN ASSEMBLY	____	____	_____
FAN	____	____	_____
MOTOR, ALTERNATING,	____	____	_____
ARROW	____	____	_____
COVER, WELDMENT	____	____	_____
CONTROL PANEL ASSEMBLY	____	____	_____
STARTER, MANUAL	____	____	_____
PANEL ASSEMBLY	____	____	_____
CONTROL, FLAME	____	____	_____
PROGRAM TIME CARD,	____	____	_____
TERMINAL BOX, 12 SGL	____	____	_____
RELAY	____	____	_____
BASE, RELAY,	____	____	_____

COMPONENTS	PASS	FAIL	REMARKS
SHIELD ASSEMBLY	____	____	
MOTOR, STARTER	____	____	
HEATER ELEMENT,	____	____	
TUMBLER SPEED REDUCER ASSEMBLY	____	____	
MOTOR, ALTERNATING	____	____	
MOUNTING BRACKET ASSEMBLY	____	____	
BASE ASSEMBLY	____	____	
TUMBLER ASSEMBLY	____	____	
TIE ROD	____	____	
RIB, TUMBLER,	____	____	
SPIDER ASSEMBLY	____	____	
TUMBLER, CLOTHES DRYER	____	____	
EXHAUST TIE DOWN ASSEMBLY#1	____	____	
LEG	____	____	
STRAP, WEBBING,	____	____	
LOOP	____	____	
THREAD	____	____	
EXHAUST TIE DOWN ASSEMBLY#2	____	____	
LEG	____	____	
STRAP	____	____	
LOOP	____	____	
THREAD	____	____	
CONDUIT ASSEMBLY	____	____	
GROUND ROD, SECTION	____	____	
CONNECTOR, GROUND ROD	____	____	
WIRE, #8 STRANDED	____	____	
CONDUIT OUTLET	____	____	
COVER	____	____	
COVER, BLANK	____	____	
BODY, CONNECTOR	____	____	
COVER,CONNECTER	____	____	
PLUG, NYLON	____	____	
PLUG, COVER	____	____	
CONNECTOR	____	____	
BOX, TWO GANG	____	____	
BOX CONNECTOR,	____	____	
CLOTHES BIN ASSEMBLY	____	____	
HANDLE, SHORT	____	____	
HANDLE, LONG			
SIDE			
BASE			
COUPLING			
STAND, CLOTHES BIN			
CASTOR			
PLATFORM			
POWER CABLE ASSEMBLY			
BODY			

COMPONENTS	PASS	FAIL	REMARKS
SHIELD, ELECTRICAL CABLE			

COMPONENTS: REMARKS:

LAUNDRY FACILITY BARE BASE
MAIN PLATFORM ASSEMBLY,
(SEE FIGURE 7 2)
STORAGE BIN ASSEMBLY,
(SEE FIGURE 7 3)
LAUNDRY WASHER ASSEMBLY,
(SEE FIGURE 7-4)
LAUNDRY WASHER ASSEMBLY,
(SEE FIGURE 7 7)
CLAMP ASSEMBLY,
(SEE FIGURE 7-13)
COUPLING
COUPLING HALF,
QUICK DISCONNECT,
CAM-LOCKINC ALL ENDS
PLUG, SQ HD,
ELBOW, ST BRASS
BUSHING, BRASS,
COMPRESSOR UNIT,
RECIPROCATING,
(SEE FIGURE 7-14)
CONTROLLER AND
ELECTRICAL PANEL,
(SEE FIGURE 7-16)
WATER HEATER,
(SEE FIGURE 7-22)
HEATER FUEL LINE ASSEMBLY,
(SEE FIGURE 7-23)
HEATER TIEDOWN ASSEMBLY,
(SEE FIGURE 7-24)
LAUNDRY EXTRACTOR,
(SEE FIGURE 7-25)
TIE DOWN CLIP ASSEMBLY,
(SEE FIGURE 7-30)
WATER PUMP ASSEMBLY,
(SEE FIGURE 7-3 1)
HOSE CONNECT ASSEMBLY,
(SEE FIGURE 7 32)
PUMP TIEDOWN ASSEMBLY,
(SEE FIGURE 7 33)
DRYER ASSEMBLY,
(SEE FIGURE 7-34)
DRYER FUEL LINE ASSEMBLY,
(SEE FIGURE 7-23)
EXHAUST HOSE
TIEDOWN ASSEMBLY,
(SEE FIGURE 7-45)
EXHAUST HOSE
TIEDOWN ASSEMBLY,
(SEE, FIGURE 7-46)
CONDUIT ASSEMBLY,

COMPONENTS:	REMARKS:
(SEE FIGURE 7-47)	
RAIL, SIDE, 84 IN LG	
CLOTHES BIN ASSEMBLY,	
(SEE, FIGURE 7-49)	
POWER CABLEASSEMBLY,	
(SEE FIGURE, 7 49)	
SPACER	
COVER ASSEMBLY RED 1, 2, & 3	
MAIN PLATFORM ASSEMBLY	
PLATFORM, LEFT ASSEMBLY	
PLATFORM, FRAME ASSEMBLY	
DECK, LARGE TOP ASSEMBLY	
DECK, SMALL TOP ASSEMBLY	
DECK, LARGE BOTTOM ASSEMBLY	
DECK, SMALL BOTTOM ASSEMBLY	
RAIL	
RAIL, SIDE	
SLEEVE	
STRAP, RETAINING,	
PLATFORM, RIGHT ASSEMBLY	
JOINING PANEL ASSEMBLY	
STORAGE BIN ASSEMBLY	
BIN, LARGE	
PLATFORM	
BIN, SMALL	
COVER ASSEMBLY	
FASTENER, LINK LOCK	
TRAY	
LAUNDRY WASHER	
WASHER ASSEMBLY,	
(SEE FIGURE 7-5)	
PLATE, TANK MOUNTING	
ELBOW, PIPE,	
TEE, PIPE, STL,	
COCK, DRAIN,	
WASHER ASSEMBLY, OPEN END	
COVER, BASE SIDE LEFT	
COVER, BASE FRONT	
COVER, BASE SIDE RIGHT	
SUPPLY INJECTOR ASSEMBLY	
SHELL ASSEMBLY	
SHELL FRONT ASSEMBLY	
SHELL, EXTRUSION	
RING, SHELL	
PLATE, MOUNTING	
MICROSWITCH	
CAM, CONTROL	
HANDLE ASSEMBLY	
DOOR, ASSEMBLY	
BRACKET, HINGE	
CYLINDER ASSEMBLY	

COMPONENTS:	REMARKS:
HOUSING, SHAFT SEAL	
GASKET, SHAFTSEAL	
SEAL, PLAIN, STL,	
COVER, SHAFT RETAINER	
SPACER, SHAFT RETAINER	
KEY, MACHINE, STL	
SPIDER,	
GEAR ASSEMBLY,	
SPEED DECREASER	
MOTOR, ALTERNATING	
MOUNT, MOTOR	
BRACKET, MOTOR MOUNT, LEFT	
BRACKET, MOTOR MOUNT, RIGHT	
BELT GUARD ASSEMBLY	
BRACKET, BELT UPPER	
BELT, V, RBR,	
BRACKET, BELT, LOWER LEFT	
PULLEY, GROOVE,	
BUSHING, SLEEVE	
V-PULLEY	
BUSHING, SLEEVE	
COVER, SYPHON	
BREAKER	
PIPE, ELBOW	
WATER LEVEL FLOAT,	
CHAMBER ASSEMBLY,	
(SEE FIC3URE 7-6)	
SOAP CHUTE	
COVER, SOAP CHUTE	
HINGE, SOAP CHUTE	
ROD, SOAP CHUTE	
PIPE, METALLIC	
HOSE, NONMETALLIC,	
PIPE, WATER INLET	
VALVE, ANGLE,	
WATER LEVEL FLOAT	
CHAMBER ASSEMBLY	
SWITCH, LIQUID LEVEL	
TUBING, GLASS,	
CLAMP, LOOP	
BRACKET, LEVEL CONTROL	
BRACKET, TOP FLOAT	
CHAMBER	
BRACKET, BOTTOM	
FLOAT CHAMBER	
FLOAT ASSEMBLY,	
LIQUID LEVEL	
FLOAT	
ROD, FLOAT,	
SPEED NUT	
LAUNDRY WASHER ASSEMBLY	

COMPONENTS:	REMARKS:
FRAME ASSEMBLY	
DOOR ASSEMBLY, (SEE FIGURE 7-8)	
DOOR LOCK ASSEMBLY, (SEE FIGURE 7-9)	
DRAW BAND, WASHER EXTRACTOR	
GASKET, RBR CHLOROPRENE	
DRUM FRONT	
CYLINDER ASSEMBLY	
SPIDER AND SHAFT ASSEMBLY	
ROD, THREADED END	
RING, GASKET CLAMP	
GASKET, SOCK	
MOTOR	
PLATE, MOTOR MOUNTING	
ROD, MOTOR ADJUSTING	
BELT	
PULLFY, GROOVE,	
BUSHING, SHEAVE	
DRUM ASSEMBLY	
WATER INLET ASSEMBLY, (SEE FIGURE 7-10)	
SHEAVE	
BUSHING, SHEAVE	
GEAR ASSEMBLY,	
PLATE, MOUNTING	
SEAL AND CARRIAGE ASSEMBLY,	
SEAL, PLAIN	
DISPENSER ASSEMBLY, (SEE FIGURE 7-11)	
GAUGE,TEMPERATURE	
BOTTLE, SUPPLY	
VALVE ASSEMBLY,DRAIN, (SEE FIGURE 7-12)	
PLUG, PIPE	
HOSE, DRAIN	
DOOR ASSEMBLY	
DOOR HINGE AND	
HANDLE	
BASE, DOOR HINGE	
BUSHING, FLANGE,	
PIN, DOOR HINGE	
BEARING, WASHER,	
BAR, DOOR	
FASTENER, PAWL	
BOLT, PIVOT	
BUSHING, SLEEVE	
RING, RETAINING	
WINDOW, OBSERVATION, GLASS,	
GASKET, DOOR GLASS	

COMPONENTS:	REMARKS:
FRAME, DOOR	
DRAW BAND, DOOR	
GASKET, DRAW BAND	
GASKET, DOOR	
DOOR LOCK ASSEMBLY	
DOOR LOCK COVER AND SWITCH	
COVER, DOOR LOCK	
SWITCH, PUSH	
BOOT, DUST AND MOISTURE SEAL	
BRACKET, MOUNTING	
BUSHING, ELECTRICAL	
CONDUCTOR,	
SOLENOID,	
SWITCH,	
PLATE, DOOR LOCK	
SPRING, DOOR LOCK	
BAR, DOOR LOCK	
SPRING, DOOR LATCH	
WATER INLET ASSEMBLY	
LEVER, MANUAL CONTROL	
CLEVIS, ROD END,	
CYLINDER ASSEMBLY,	
ROD, ADJUSTINC STUD	
BRACKET, MOUNTING	
COUPLER, FEMALE	
COUPLING HALF,QUICK	
DISCONNECT,	
ELBOW, PIPE,	
NIPPLE, PIPE,	
PIPE, METALLIC,	
ELBOW, PIPE TO HOSE,	
ELBOW, PIPE,	
BUSHING, PIPE	
TEE, PIPE	
VALVE, BALL,	
NIPPLE, PIPE,	
DISPENSER ASSEMBLY	
DISPENSER	
COVER	
HOSE, SUPPLY1	
SUPPLY HOSE, AIR	
HOSE, SUPPLY 2	
HOSE, SUPPLY 3	
HOSE, SUPPLY 4	
FITTING, HOSE	
COUPLING, PIPE,	
HOSE, SUPPLY INLET	
ADAPTER, STRAIGHT	
VALVE, SOLENOID,	
MANIFOLD, SUPPLY	
BRACKET, MANIFOLD	

COMPONENTS:	REMARKS:
MOUNTING	
DRAIN VALVE ASSEMBLY	
PLATE,TOP	
BELLOWS, RUBBER,	
ADAPTER, STRAIGHT,	
PLATE, MOUNTING	
BRACKET	
HOSE, NONMETALLIC,	
PINCH TUBE	
CLAMP ASSEMBLY	
ANGLE	
ROD,THREADED, SHORT	
RING, HANGER	
AIR COMPRESSOR ASSEMBLY	
GRILLE, METAL	
HANDLE, DOOR, L STYLE	
KIT, SWITCH, (SEE FIGURE 7-15)	
HOUSING, AIR COMPRESSOR	
CYLINDER, HEAD ASSEMBLY,	
RIGHT HAND	
CYLINDER HEAD ASSEMBLY,	
LEFT HAND	
MOTOR, ALTERNATING	
CABLE ASSEMBLY,	
PRESSURE SWITCH ASSEMBLY	
SWITCH, PRESSURE	
PLUG, BUTTON	
WIRE ASSEMBLY, BLK	
WIRE ASSEMBLY, WHT	
CONTROLLER AND ELECTRICAL PANELSUPPORT FRAME ASSEMBLY	
FACE PLATE, LAUNDRY,	
COVER, CONTROLLER	
CONTROLLER ASSEMBLY	
HEAD ASSEMBLY,	
CONTROL BOX, (SEE FIGURE 7-17)	
CONTROL BOX ASSEMBLY,	
(SEE FIGURE 7-18)	
CONTROL CHASIS	
ASSEMBLY, LAUNDRY,	
(SEE FIGURE 7-19)	
HOSE, LOW PRESSURE	
ADAPTER, STRAIGHT	
SLEEVE	
FIRE EXTINGUISHER	
PLATE, MOUNTING	
STAND, CONTROLLER SUPPORT	
LOAD CENTER	
ENCLOSURE	
BRACKET, INTERIOR MOUNT	
KIT, INTERIOR TRIM	

COMPONENTS:	REMARKS:
CAP, END SEAL	
MAIN BREAKER, 30 AMP	
CIRCUIT BREAKER, 20 AMP	
BOX, 3 GANG	
GASKET, SYNTH-RBR,	
CONNECTOR, RECEPTACLE	
OUTLET	
COVER, CONDUIT	
COVER, LIFT	
SWITCH, MOTOR STARTING	
HEAD ASSEMBLY	
WINDOW, OBSERVATION,	
LATCH, SPECIAL	
LAMP, 28V	
SOCKET, LAMP	
NAME PLATE	
WARNING	
NAME PLATE,	
TUBING,	
TYRAP,	
BRACKET, RECEPTACLE	
RECEPTACLE	
ANGLE, CENTER	
DOOR ASSEMBLY, PLASTIC	
WET PART, LAUNDRY	
PARTITION, SWITCH	
SKIRT, TIMING,LAUNDRY	
REAR ASSEMBLY	
BACK	
POWER SUPPLY	
VALVE, SOLENOID,	
STRAINER, SEDIMENT,	
NIPPLE, PIPE,	
ANGLE	
PLUG, PIPE	
BLOCK, MANIFOLD,	
CONTROL CHASIS ASSEMBLY	
CONTROL PANEL ASSEMBLY,	
(SEE FIGURE 7-20)	
FUSE, CARTRIDGE,	
FUSEHOLDER,	
VALVE, SOLENOID,	
VALVE, AIR CONTROL, 3 WAY	
RELAY, 3PDT, IO AMP	
SWITCH, PRESSURE	
RELAY,	
TIMING MOVEMENT,	
MECHANICAL,	
(SEE FIGURE 7-21)	
CONTROL PANEL ASSEMBLY	
PANEL,CONTROL	

COMPONENTS:	REMARKS:
TIMER, SEQUENTIAL	
SWITCH, TOGGLE,	
COVER, SWITCH	
REVERSING TIMER ASSEMBLY	
SHAFT, SHOULDERED,	
SWITCH, SENSITIVE,	
ADAPTER, SWITCH	
CAM, CONTROL	
SETSCREW,	
BRACKET, TIMER	
LAUNDRY EXTRACTOR ASSEMBLY	
EXTRACTOR, BOCK MOISTRITE AND SPEEDRY	
MOTOR ASSEMBLY, (SEE FIGURE 7-26)	
MOTOR ASSEMBLY, (SEE FIGURE 7-27)	
SHEAVE, PULLEY	
V-BELT	
LID	
FRAME, LID HINCE	
BASKET BALL	
LID GASKET	
CURB ASSEMBLY	
WASHER, LEAD	
RUBBER WASHER	
HOSE,	
BASKET ASSEMBLY	
POST,CENTER	
SEAL,	
CENTER UNIT ASSEMBLY, (SEE FIGURE 7-28)	
HUB, BRAKE	
BACK PANEL ASSEMBLY, (SEE FIGURE 7,29)	
BASE ASSEMBLY	
TRUNNION FRAME, ASSEMBLY	
COUPLING HALF,	
MOTOR ASSEMBLY #1	
MOTOR, 3 HP	
SWITCH,	
MOUNT, SWITCH	
COUPLING	
HUB, BODY,	
PLATE, MOTOR MOUNT	
MOTOR ASSEMBLY #2	
MOTOR	
HUB, PULLEY	
PLATE, MOTOR MOUNT	
CENTER UNIT ASSEMBLY	
PIN, STUD	

COMPONENTS:	REMARKS:
ARM,BRAKE	
ARM, OPERATING	
BRACKET	
SPRING, HELICAL, EXTENSION	
BRAKE SHOE,	
COVER, TOP END	
SHIELD, SOLENOID	
ROD, SOLENOID	
SOLENOID, BRAKE	
HUB	
BALL,BASKET	
INSERT, NYLON	
PACKING,	
CAP, BUMPER	
BUMPER RUBBERS	
CAP, TRUNNION	
RUBBER, TRUNNION	
HUB, PULLEY	
SHEAVES, PULLEY	
BACK PANEL ASSEMBLY	
BUTT0N, START	
SWITCH, PUSH-PULL,	
BUTTON, RED	
LIGHT, INDICATOR	
MICROSWITCH	
SOLENOID,	
RELAY,ELECTRO MAGNETIC	
TIMER,	
FUSE HOLDER	
FUSE, CARTRIDGE,	
TERMINAL BOARD	
COVER	
PLATE, BOTTOM	
BACK AND SIDES, CONTROL PANEL	
PLATE, MOUNT	
PLATE,TOP	
TIE DOWN CLIP ASSEMBLY	
BAR, TIE DOWN CLIP	
LEG, TIE DOWN CLIP	
PLATFORMS	
WATER PUMP ASSEMBLY	
WATER PUMP ASSEMBLY	
FRAME, AL-ALY	
SWITCH BOX ASSEMBLY	
COVERS	
COVER,BOX,FRONT	
PUMP UNIT	
BRACKET	
MOTOR, ALTERNATING	
CAP,	

COMPONENTS:	REMARKS:
COUPLING HALF,	
NIPPLE, PIPE	
HOSE CONNECTION ASSEMBLY	
SUCTION STRAINER ASSEMBLY	
COUPLING, QUICK DISCONNECT	
SUCTION HOSE ASSEMBLY	
COUPLING, HALF	
HEATER INTAKE HOSE ASSEMBLY	
WASHER, INTAKE HOSE ASSEMBLY	
HOSES, WATER,	
CLOTHES BIN DISCHARGE HOSE	
EXTRACTOR DISCHARGE HOSE	
ASSEMBLY	
PUMP TIE DOWN ASSEMBLY	
CATCH, FIXED ASSEMBLY	
CATCH, ADJUSTABLE	
PLATFORM ASSEMBLY	
DRYER ASSEMBLY	
BLOWER ASSEMBLY,	
(SEE FIGURE 7-35)	
HOSE ASSEMBLIES	
BURNER TUMBLER ASSEMBLY,	
(SEE FIGURE 7-36)	
SWITCHES, SENSITIVE	
COVER	
LIGHT, INDICATOR,	
ALARM,BUZZER	
BUZZER,	
DOOR ASSEMBLY	
CHAIN, WELDLESS	
TIMER, SEQUENTIAL	
PLATE, INDENT	
LABEL, CAUTION	
LABEL, WARNING	
ARROW	
HANDLE, DOOR	
RING ASSEMBLY	
FRONT SHELL ASSEMBLY,	
(SEE FIGURE 7-39)	
HEATER TUMBLER ASSEMBLY,	
(SEE FIGURE 7-40)	
HOSE, AIR DUCT,	
HOSE, FLEX	
EXHAUST HOSE ADAPTER	
ASSEMBLY	
DUCT, HOSE,	
REDUCER, PIPE,	
ELBOW, AIR CONDITIONING	
HEATING	
PIN ASSEMBLY	
PIN	

COMPONENTS:	REMARKS:
CHAIN, SAFETY	
HOOK, CHAIN,	
THERMOMETER	
DISCHARGE SPOUT ASSEMBLY	
COUPLING, HALF	
CONTROL, TEMPERA TURE, DIAL AND KNOB	
CONNECTOR, ELBOW,	
BOX CONNECTOR,	
FAN ASSEMBLY, (SEE FIGURE 7-41)	
COVER	
CONTROL PANEL ASSEM BLY, (SEE FIGURE 7-42)	
TUMBLER SPEED REDUCER ASSEMBLY, (SEE FIGURE 7-43)	
ROD, THREADED	
CUP, GREASE,	
CUP OIL,	
PLATES, RETAINING,	
GUARD	
CHAIN, STL, 65 LINKS	
WIRE, SAFETY	
TUMBLER ASSEMBLY, (SEE, FIGURE 7-44)	
SHELL ASSEMBLY	
TUMBLER BASE ASSEMBLY	
PANEL, SIDE	
INSULATOR,PLATE, STRIP	
BLOWER ASSEMBLY	
GUAGE, PRESSURE	
COCK, DRAIN	
TEE	
NIPPLE	
PUMP, FUEL	
SHUTTER ASSEMBLY, HOUSING	
HOUSING, BLOWER	
WHEEL, BLOWER	
MOUNT, BLOWER	
KEY	
MOTOR, ALTERNATING	
BURNER TUMBLER ASSEMBLY	
CAP FITTING	
GASKET, PEEP SIGHT,	
GLASS, PEEP HOLE	
NIPPLE	
COVER	
CABLE AND TERMINAL ASSEMBLY,	

COMPONENTS:	REMARKS:
(SEE FIGURE 7-37)	
ELECTRODE ASSEMBLY,	
(SEE FIGURE 7-38)	
BRACKET, TRANSFORMER	
TRANSFORMER	
BOX, JUNCTION	
COVER	
BOX CONNECTORS,	
CONNECTOR, STRAIGHT	
AIR PLENUM	
CABLE AND TERMINAL ASSEMBLY	
CABLE	
TERMINAL, LUG,	
ELECTRODE ASSEMBLY	
ELECTRODE	
NOZZLE ASSEMBLY	
NOZZLE	
PIPE	
BASE, BURNER	
FRONT SHELL ASSEMBLY	
DOOR	
HINGE ASSEMBLY	
HINGE	
PIN, SPRING	
FRONT, SHELL	
HEATER TUMBLER ASSEMBLY	
SCREEN ASSEMBLY,	
PANEL, COVER	
HOOD ASSEMBLY	
HOOD	
PLATE	
COVER, FRONT	
COVER, REAR	
BURNER MOUNTING ASSEMBLY	
RETURN BOX NO 5 ASSEMBLY	
COVER, ASSEMBLY	
RETURN BOX NO 3 ASSEMBLY	
RETURN BOX NO 1 ASSEMBLY	
RETURN BOX NO 4 ASSEMBLY	
RETURN BOX NO 2 ASSEMBLY	
MOUNTING PLATE ASSEMBLY	
FAN ASSEMBLY	
FAN	
MOTOR, ALTERNATING,	
ARROW	
COVER, WELDMENT	
CONTROL PANEL ASSEMBLY	
STARTER, MANUAL	
PANEL ASSEMBLY	
CONTROL, FLAME	
PROGRAM TIME CARD,	

COMPONENTS:	REMARKS:
TERMINAL BOX, 12 SGL	
RELAY	
BASE, RELAY,	
SHIELD ASSEMBLY	
MOTOR, STARTER	
HEATER ELEMENT,	
TUMBLER SPEED REDUCER ASSEMBLY	
MOTOR, ALTERNATING	
MOUNTING BRACKET ASSEMBLY	
BASE ASSEMBLY	
TUMBLER ASSEMBLY	
TIE ROD	
RIB, TUMBLER,	
SPIDER ASSEMBLY	
TUMBLER, CLOTHES DRYER	
EXHAUST TIE DOWN ASSEMBLY#1	
LEG	
STRAP, WEBBING,	
LOOP	
THREAD	
EXHAUST TIE DOWN ASSEMBLY#2	
LEG	
STRAP	
LOOP	
THREAD	
CONDUIT ASSEMBLY	
GROUND ROD, SECTION	
CONNECTOR, GROUND ROD	
WIRE, #8 STRANDED	
CONDUIT OUTLET	
COVER	
COVER, BLANK	
BODY, CONNECTOR	
COVER,CONNECTER	
PLUG, NYLON	
PLUG, COVER	
CONNECTOR	
BOX, TWO GANG	
BOX CONNECTOR,	
CLOTHES BIN ASSEMBLY	
HANDLE, SHORT	
HANDLE, LONG	
SIDE	
BASE	
COUPLING	
STAND, CLOTHES BIN	
CASTOR	
PLATFORM	
POWER CABLE ASSEMBLY	

COMPONENTS:

BODY
SHIELD, ELECTRICAL
CABLE

REMARKS:

COMPONENTS:	REMARKS:
LAUNDRY FACILITY BARE BASE	
MAIN PLATFORM ASSEMBLY,	
(SEE FIGURE 7 2)	
STORAGE BIN ASSEMBLY,	
(SEE FIGURE 7 3)	
LAUNDRY WASHER ASSEMBLY,	
(SEE FIGURE 7-4)	
LAUNDRY WASHER ASSEMBLY,	
(SEE FIGURE 7 7)	
CLAMP ASSEMBLY,	
(SEE FIGURE 7-13)	
COUPLING	
COUPLING HALF,	
QUICK DISCONNECT,	
CAM-LOCKINC ALL ENDS	
PLUG, SQ HD,	
ELBOW, ST BRASS	
BUSHING, BRASS,	
COMPRESSOR UNIT,	
RECIPROCATING,	
(SEE FIGURE 7-14)	
CONTROLLER AND	
ELECTRICAL PANEL,	
(SEE FIGURE 7-16)	
WATER HEATER,	
(SEE FIGURE 7-22)	
HEATER FUEL LINE ASSEMBLY,	
(SEE FIGURE 7-23)	
HEATER TIEDOWN ASSEMBLY,	
(SEE FIGURE 7-24)	
LAUNDRY EXTRACTOR,	
(SEE FIGURE 7-25)	
TIE DOWN CLIP ASSEMBLY,	
(SEE FIGURE 7-30)	
WATER PUMP ASSEMBLY,	
(SEE FIGURE 7-3 1)	
HOSE CONNECT ASSEMBLY,	
(SEE FIGURE 7 32)	
PUMP TIEDOWN ASSEMBLY,	
(SEE FIGURE 7 33)	
DRYER ASSEMBLY,	
(SEE FIGURE 7-34)	
DRYER FUEL LINE ASSEMBLY,	
(SEE FIGURE 7-23)	
EXHAUST HOSE	
TIEDOWN ASSEMBLY,	
(SEE FIGURE 7-45)	
EXHAUST HOSE	
TIEDOWN ASSEMBLY,	
(SEE, FIGURE 7-46)	

COMPONENTS:	REMARKS:
CONDUIT ASSEMBLY,	
(SEE FIGURE 7-47)	
RAIL, SIDE, 84 IN LG	
CLOTHES BIN ASSEMBLY,	
(SEE, FIGURE 7-49)	
POWER CABLEASSEMBLY,	
(SEE FIGURE, 7 49)	
SPACER	
COVER ASSEMBLY RED 1, 2, & 3	
MAIN PLATFORM ASSEMBLY	
PLATFORM, LEFT ASSEMBLY	
PLATFORM, FRAME ASSEMBLY	
DECK, LARGE TOP ASSEMBLY	
DECK, SMALL TOP ASSEMBLY	
DECK, LARGE BOTTOM ASSEMBLY	
DECK, SMALL BOTTOM ASSEMBLY	
RAIL	
RAIL, SIDE	
SLEEVE	
STRAP, RETAINING,	
PLATFORM, RIGHT ASSEMBLY	
JOINING PANEL ASSEMBLY	
STORAGE BIN ASSEMBLY	
BIN, LARGE	
PLATFORM	
BIN, SMALL	
COVER ASSEMBLY	
FASTENER, LINK LOCK	
TRAY	
LAUNDRY WASHER	
WASHER ASSEMBLY,	
(SEE FIGURE 7-5)	
PLATE, TANK MOUNTING	
ELBOW, PIPE,	
TEE, PIPE, STL,	
COCK, DRAIN,	
WASHER ASSEMBLY, OPEN END	
COVER, BASE SIDE LEFT	
COVER, BASE FRONT	
COVER, BASE SIDE RIGHT	
SUPPLY INJECTOR ASSEMBLY	
SHELL ASSEMBLY	
SHELL FRONT ASSEMBLY	
SHELL, EXTRUSION	
RING, SHELL	
PLATE, MOUNTING	
MICROSWITCH	
CAM, CONTROL	
HANDLE ASSEMBLY	
DOOR, ASSEMBLY	

COMPONENTS:	REMARKS:
BRACKET, HINGE	
CYLINDER ASSEMBLY	
HOUSING, SHAFT SEAL	
GASKET, SHAFTSEAL	
SEAL, PLAIN, STL,	
COVER, SHAFT RETAINER	
SPACER, SHAFT RETAINER	
KEY, MACHINE, STL	
SPIDER,	
GEAR ASSEMBLY,	
SPEED DECREASER	
MOTOR, ALTERNATING	
MOUNT, MOTOR	
BRACKET, MOTOR MOUNT, LEFT	
BRACKET, MOTOR MOUNT, RIGHT	
BELT GUARD ASSEMBLY	
BRACKET, BELT UPPER	
BELT, V, RBR,	
BRACKET, BELT, LOWER LEFT	
PULLEY, GROOVE,	
BUSHING, SLEEVE	
V-PULLEY	
BUSHING, SLEEVE	
COVER, SYPHON	
BREAKER	
PIPE, ELBOW	
WATER LEVEL FLOAT,	
CHAMBER ASSEMBLY,	
(SEE FIC3URE 7-6)	
SOAP CHUTE	
COVER, SOAP CHUTE	
HINGE, SOAP CHUTE	
ROD, SOAP CHUTE	
PIPE, METALLIC	
HOSE, NONMETALLIC,	
PIPE, WATER INLET	
VALVE, ANGLE,	
WATER LEVEL FLOAT CHAMBER ASSEMBLY	
SWITCH, LIQUID LEVEL	
TUBING, GLASS,	
CLAMP, LOOP	
BRACKET, LEVEL CONTROL	
BRACKET, TOP FLOAT CHAMBER	
BRACKET, BOTTOM FLOAT CHAMBER	
FLOAT ASSEMBLY, LIQUID LEVEL	
FLOAT	

COMPONENTS:	REMARKS:
ROD, FLOAT,	
SPEED NUT	
LAUNDRY WASHER ASSEMBLY	
FRAME ASSEMBLY	
DOOR ASSEMBLY, (SEE FIGURE 7-8)	
DOOR LOCK ASSEMBLY, (SEE FIGURE 7-9)	
DRAW BAND, WASHER EXTRACTOR	
GASKET, RBR CHLOROPRENE	
DRUM FRONT	
CYLINDER ASSEMBLY	
SPIDER AND SHAFT ASSEMBLY	
ROD, THREADED END	
RING, GASKET CLAMP	
GASKET, SOCK	
MOTOR	
PLATE, MOTOR MOUNTING	
ROD, MOTOR ADJUSTING	
BELT	
PULLFY, GROOVE,	
BUSHING, SHEAVE	
DRUM ASSEMBLY	
WATER INLET ASSEMBLY, (SEE FIGURE 7-10)	
SHEAVE	
BUSHING, SHEAVE	
GEAR ASSEMBLY,	
PLATE, MOUNTING	
SEAL AND CARRIAGE ASSEMBLY,	
SEAL, PLAIN	
DISPENSER ASSEMBLY, (SEE FIGURE 7-11)	
GAUGE,TEMPERATURE	
BOTTLE, SUPPLY	
VALVE ASSEMBLY,DRAIN, (SEE FIGURE 7-12)	
PLUG, PIPE	
HOSE, DRAIN	
DOOR ASSEMBLY	
DOOR HINGE AND HANDLE	
BASE, DOOR HINGE	
BUSHING, FLANGE,	
PIN, DOOR HINGE	
BEARING, WASHER,	
BAR, DOOR	
FASTENER, PAWL	
BOLT, PIVOT	

COMPONENTS:	REMARKS:
BUSHING, SLEEVE	
RING, RETAINING	
WINDOW, OBSERVATION, GLASS,	
GASKET, DOOR GLASS	
FRAME, DOOR	
DRAW BAND, DOOR	
GASKET, DRAW BAND	
GASKET, DOOR	
DOOR LOCK ASSEMBLY	
DOOR LOCK COVER AND SWITCH	
COVER, DOOR LOCK	
SWITCH, PUSH	
BOOT, DUST AND MOISTURE SEAL	
BRACKET, MOUNTING	
BUSHING, ELECTRICAL	
CONDUCTOR,	
SOLENOID,	
SWITCH,	
PLATE, DOOR LOCK	
SPRING, DOOR LOCK	
BAR, DOOR LOCK	
SPRING, DOOR LATCH	
WATER INLET ASSEMBLY	
LEVER, MANUAL CONTROL	
CLEVIS, ROD END,	
CYLINDER ASSEMBLY,	
ROD, ADJUSTINC STUD	
BRACKET, MOUNTING	
COUPLER, FEMALE	
COUPLING HALF,QUICK	
DISCONNECT,	
ELBOW, PIPE,	
NIPPLE, PIPE,	
PIPE, METALLIC,	
ELBOW, PIPE TO HOSE,	
ELBOW, PIPE,	
BUSHING, PIPE	
TEE, PIPE	
VALVE, BALL,	
NIPPLE, PIPE,	
DISPENSER ASSEMBLY	
DISPENSER	
COVER	
HOSE, SUPPLY1	
SUPPLY HOSE, AIR	
HOSE, SUPPLY 2	
HOSE, SUPPLY 3	
HOSE, SUPPLY 4	
FITTING, HOSE	
COUPLING, PIPE,	

COMPONENTS:	REMARKS:
HOSE, SUPPLY INLET	
ADAPTER, STRAIGHT	
VALVE, SOLENOID,	
MANIFOLD, SUPPLY	
BRACKET, MANIFOLD	
MOUNTING	
DRAIN VALVE ASSEMBLY	
PLATE,TOP	
BELLOWS, RUBBER,	
ADAPTER, STRAIGHT,	
PLATE, MOUNTING	
BRACKET	
HOSE, NONMETALLIC,	
PINCH TUBE	
CLAMP ASSEMBLY	
ANGLE	
ROD,THREADED, SHORT	
RING, HANGER	
AIR COMPRESSOR ASSEMBLY	
GRILLE, METAL	
HANDLE, DOOR, L STYLE	
KIT, SWITCH, (SEE FIGURE 7-15)	
HOUSING, AIR COMPRESSOR	
CYLINDER, HEAD ASSEMBLY,	
RIGHT HAND	
CYLINDER HEAD ASSEMBLY,	
LEFT HAND	
MOTOR, ALTERNATING	
CABLE ASSEMBLY,	
PRESSURE SWITCH ASSEMBLY	
SWITCH, PRESSURE	
PLUG, BUTTON	
WIRE ASSEMBLY, BLK	
WIRE ASSEMBLY, WHT	
CONTROLLER AND ELECTRICAL PANELSUPPORT FRAME ASSEMBLY	
FACE PLATE, LAUNDRY,	
COVER, CONTROLLER	
CONTROLLER ASSEMBLY	
HEAD ASSEMBLY,	
CONTROL BOX, (SEE FIGURE 7-17)	
CONTROL BOX ASSEMBLY,	
(SEE FIGURE 7-18)	
CONTROL CHASIS	
ASSEMBLY, LAUNDRY,	
(SEE FIGURE 7-19)	
HOSE, LOW PRESSURE	
ADAPTER, STRAIGHT	
SLEEVE	

COMPONENTS:	REMARKS:
FIRE EXTINGUISHER	
PLATE, MOUNTING	
STAND, CONTROLLER SUPPORT	
LOAD CENTER	
ENCLOSURE	
BRACKET, INTERIOR MOUNT	
KIT, INTERIOR TRIM	
CAP, END SEAL	
MAIN BREAKER, 30 AMP	
CIRCUIT BREAKER, 20 AMP	
BOX, 3 GANG	
GASKET, SYNTH-RBR,	
CONNECTOR, RECEPTACLE	
OUTLET	
COVER, CONDUIT	
COVER, LIFT	
SWITCH, MOTOR STARTING	
HEAD ASSEMBLY	
WINDOW, OBSERVATION,	
LATCH, SPECIAL	
LAMP, 28V	
SOCKET, LAMP	
NAME PLATE	
WARNING	
NAME PLATE,	
TUBING,	
TYRAP,	
BRACKET, RECEPTACLE	
RECEPTACLE	
ANGLE, CENTER	
DOOR ASSEMBLY, PLASTIC	
WET PART, LAUNDRY	
PARTITION, SWITCH	
SKIRT, TIMING,LAUNDRY	
REAR ASSEMBLY	
BACK	
POWER SUPPLY	
VALVE, SOLENOID,	
STRAINER, SEDIMENT,	
NIPPLE, PIPE,	
ANGLE	
PLUG, PIPE	
BLOCK, MANIFOLD,	
CONTROL CHASIS ASSEMBLY	
CONTROL PANEL ASSEMBLY,	
(SEE FIGURE 7-20)	
FUSE, CARTRIDGE,	
FUSEHOLDER,	
VALVE, SOLENOID,	
VALVE, AIR CONTROL, 3 WAY	

COMPONENTS:	REMARKS:
RELAY, 3PDT, IO AMP	
SWITCH, PRESSURE	
RELAY,	
TIMING MOVEMENT,	
MECHANICAL,	
(SEE FIGURE 7-21)	
CONTROL PANEL ASSEMBLY	
PANEL,CONTROL	
TIMER, SEQUENTIAL	
SWITCH, TOGGLE,	
COVER, SWITCH	
REVERSING TIMER ASSEMBLY	
SHAFT, SHOULDERED,	
SWITCH, SENSITIVE,	
ADAPTER, SWITCH	
CAM, CONTROL	
SETSCREW,	
BRACKET, TIMER	
LAUNDRY EXTRACTOR ASSEMBLY	
EXTRACTOR, BOCK MOISTRITE AND SPEEDRY	
MOTOR ASSEMBLY,	
(SEE FIGURE 7-26)	
MOTOR ASSEMBLY,	
(SEE FIGURE 7-27)	
SHEAVE, PULLEY	
V-BELT	
LID	
FRAME, LID HINCE	
BASKET BALL	
LID GASKET	
CURB ASSEMBLY	
WASHER, LEAD	
RUBBER WASHER	
HOSE,	
BASKET ASSEMBLY	
POST,CENTER	
SEAL,	
CENTER UNIT ASSEMBLY,	
(SEE FIGURE 7-28)	
HUB, BRAKE	
BACK PANEL ASSEMBLY,	
(SEE FIGURE 7,29)	
BASE ASSEMBLY	
TRUNNION FRAME, ASSEMBLY	
COUPLING HALF,	
MOTOR ASSEMBLY #1	
MOTOR, 3 HP	
SWITCH,	

COMPONENTS:	REMARKS:
MOUNT, SWITCH	
COUPLING	
HUB, BODY,	
PLATE, MOTOR MOUNT	
MOTOR ASSEMBLY #2	
MOTOR	
HUB, PULLEY	
PLATE, MOTOR MOUNT	
CENTER UNIT ASSEMBLY	
PIN, STUD	
ARM,BRAKE	
ARM, OPERATING	
BRACKET	
SPRING, HELICAL, EXTENSION	
BRAKE SHOE,	
COVER, TOP END	
SHIELD, SOLENOID	
ROD, SOLENOID	
SOLENOID, BRAKE	
HUB	
BALL,BASKET	
INSERT, NYLON	
PACKING,	
CAP, BUMPER	
BUMPER RUBBERS	
CAP, TRUNNION	
RUBBER, TRUNNION	
HUB, PULLEY	
SHEAVES, PULLEY	
BACK PANEL ASSEMBLY	
BUTT0N, START	
SWITCH, PUSH-PULL,	
BUTTON, RED	
LIGHT, INDICATOR	
MICROSWITCH	
SOLENOID,	
RELAY,ELECTRO MAGNETIC	
TIMER,	
FUSE HOLDER	
FUSE, CARTRIDGE,	
TERMINAL BOARD	
COVER	
PLATE, BOTTOM	
BACK AND SIDES, CONTROL PANEL	
PLATE, MOUNT	
PLATE,TOP	
TIE DOWN CLIP ASSEMBLY	
BAR, TIE DOWN CLIP	
LEG, TIE DOWN CLIP	

COMPONENTS:	REMARKS:
PLATFORMS	
WATER PUMP ASSEMBLY	
WATER PUMP ASSEMBLY	
FRAME, AL-ALY	
SWITCH BOX ASSEMBLY	
COVERS	
COVER,BOX,FRONT	
PUMP UNIT	
BRACKET	
MOTOR, ALTERNATING	
CAP,	
COUPLING HALF,	
NIPPLE, PIPE	
HOSE CONNECTION ASSEMBLY	
SUCTION STRAINER ASSEMBLY	
COUPLING, QUICK DISCONNECT	
SUCTION HOSE ASSEMBLY	
COUPLING, HALF	
HEATER INTAKE HOSE ASSEMBLY	
WASHER, INTAKE HOSE ASSEMBLY	
HOSES, WATER,	
CLOTHES BIN DISCHARGE HOSE	
EXTRACTOR DISCHARGE HOSE ASSEMBLY	
PUMP TIE DOWN ASSEMBLY	
CATCH, FIXED ASSEMBLY	
CATCH, ADJUSTABLE	
PLATFORM ASSEMBLY	
DRYER ASSEMBLY	
BLOWER ASSEMBLY, (SEE FIGURE 7-35)	
HOSE ASSEMBLIES	
BURNER TUMBLER ASSEMBLY, (SEE FIGURE 7-36)	
SWITCHES, SENSITIVE	
COVER	
LIGHT, INDICATOR,	
ALARM,BUZZER	
BUZZER,	
DOOR ASSEMBLY	
CHAIN, WELDLESS	
TIMER, SEQUENTIAL	
PLATE, INDENT	
LABEL, CAUTION	
LABEL, WARNING	
ARROW	
HANDLE, DOOR	
RING ASSEMBLY	
FRONT SHELL ASSEMBLY, (SEE FIGURE 7-39)	

COMPONENTS:	REMARKS:
HEATER TUMBLER ASSEMBLY, (SEE FIGURE 7-40)	
HOSE, AIR DUCT,	
HOSE, FLEX	
EXHAUST HOSE ADAPTER ASSEMBLY	
DUCT, HOSE,	
REDUCER, PIPE,	
ELBOW, AIR CONDITIONING HEATING	
PIN ASSEMBLY	
PIN	
CHAIN, SAFETY	
HOOK, CHAIN,	
THERMOMETER	
DISCHARGE SPOUT ASSEMBLY	
COUPLING, HALF	
CONTROL, TEMPERA TURE, DIAL AND KNOB	
CONNECTOR, ELBOW,	
BOX CONNECTOR,	
FAN ASSEMBLY, (SEE FIGURE 7-41)	
COVER	
CONTROL PANEL ASSEM BLY, (SEE FIGURE 7-42)	
TUMBLER SPEED REDUCER ASSEMBLY, (SEE FIGURE 7-43)	
ROD, THREADED	
CUP, GREASE,	
CUP OIL,	
PLATES, RETAINING,	
GUARD	
CHAIN, STL, 65 LINKS	
WIRE, SAFETY	
TUMBLER ASSEMBLY, (SEE, FIGURE 7-44)	
SHELL ASSEMBLY	
TUMBLER BASE ASSEMBLY	
PANEL, SIDE	
INSULATOR,PLATE, STRIP	
BLOWER ASSEMBLY	
GUAGE, PRESSURE	
COCK, DRAIN	
TEE	
NIPPLE	
PUMP, FUEL	
SHUTTER ASSEMBLY, HOUSING	

COMPONENTS:	REMARKS:
HOUSING, BLOWER	
WHEEL, BLOWER	
MOUNT, BLOWER	
KEY	
MOTOR, ALTERNATING	
BURNER TUMBLER ASSEMBLY	
CAP FITTING	
GASKET, PEEP SIGHT,	
GLASS, PEEP HOLE	
NIPPLE	
COVER	
CABLE AND TERMINAL	
ASSEMBLY,	
(SEE FIGURE 7-37)	
ELECTRODE ASSEMBLY,	
(SEE FIGURE 7-38)	
BRACKET, TRANSFORMER	
TRANSFORMER	
BOX, JUNCTION	
COVER	
BOX CONNECTORS,	
CONNECTOR, STRAIGHT	
AIR PLENUM	
CABLE AND TERMINAL ASSEMBLY	
CABLE	
TERMINAL, LUG,	
ELECTRODE ASSEMBLY	
ELECTRODE	
NOZZLE ASSEMBLY	
NOZZLE	
PIPE	
BASE, BURNER	
FRONT SHELL ASSEMBLY	
DOOR	
HINGE ASSEMBLY	
HINGE	
PIN, SPRING	
FRONT, SHELL	
HEATER TUMBLER ASSEMBLY	
SCREEN ASSEMBLY,	
PANEL, COVER	
HOOD ASSEMBLY	
HOOD	
PLATE	
COVER, FRONT	
COVER, REAR	
BURNER MOUNTING ASSEMBLY	
RETURN BOX NO 5 ASSEMBLY	
COVER, ASSEMBLY	

LIST OF REPAIR PARTS AND ASSEMBLIES REQUIRED FOR REPAIRS

COMPONENTS:	REMARKS:
RETURN BOX NO 3 ASSEMBLY	
RETURN BOX NO 1 ASSEMBLY	
RETURN BOX NO 4 ASSEMBLY	
RETURN BOX NO 2 ASSEMBLY	
MOUNTING PLATE ASSEMBLY	
FAN ASSEMBLY	
FAN	
MOTOR, ALTERNATING,	
ARROW	
COVER, WELDMENT	
CONTROL PANEL ASSEMBLY	
STARTER, MANUAL	
PANEL ASSEMBLY	
CONTROL, FLAME	
PROGRAM TIME CARD,	
TERMINAL BOX, 12 SGL	
RELAY	
BASE, RELAY,	
SHIELD ASSEMBLY	
MOTOR, STARTER	
HEATER ELEMENT,	
TUMBLER SPEED REDUCER ASSEMBLY	
MOTOR, ALTERNATING	
MOUNTING BRACKET ASSEMBLY	
BASE ASSEMBLY	
TUMBLER ASSEMBLY	
TIE ROD	
RIB, TUMBLER,	
SPIDER ASSEMBLY	
TUMBLER, CLOTHES DRYER	
EXHAUST TIE DOWN ASSEMBLY#1	
LEG	
STRAP, WEBBING,	
LOOP	
THREAD	
EXHAUST TIE DOWN ASSEMBLY#2	
LEG	
STRAP	
LOOP	
THREAD	
CONDUIT ASSEMBLY	
GROUND ROD, SECTION	
CONNECTOR, GROUND ROD	
WIRE, #8 STRANDED	
CONDUIT OUTLET	
COVER	
COVER, BLANK	

COMPONENTS:	REMARKS:
BODY, CONNECTOR	
COVER,CONNECTER	
PLUG, NYLON	
PLUG, COVER	
CONNECTOR	
BOX, TWO GANG	
BOX CONNECTOR,	
CLOTHES BIN ASSEMBLY	
HANDLE, SHORT	
HANDLE, LONG	
SIDE	
BASE	
COUPLING	
STAND, CLOTHES BIN	
CASTOR	
PLATFORM	
POWER CABLE ASSEMBLY	
BODY	
SHIELD, ELECTRICAL	
CABLE	

CONTRACT DATA REQUIREMENTS LIST

(1 Data Item)

Form Approved
OMB No. 0704-0188

A. CONTRACT LINE ITEM NO.	B. EXHIBIT	C. CATEGORY: TDP ____ TM ____ OTHER X

D. SYSTEM/ITEM	E. CONTRACT/PR NO.	F. CONTRACTOR
Laundry Facility		

1. DATA ITEM NO.	2. TITLE OF DATA ITEM	3. SUBTITLE
A001	Contractor's Progress, Status, and Management Report	Management

4. AUTHORITY *(Data Acquisition Document No.)*	5. CONTRACT REFERENCE	6. REQUIRING OFFICE
DI-MGMT-80227	SOW 4.2	MCLBA (837)

7. DD 250 REQ.	9. DIST STATEMENT REQUIRED	10. FREQUENCY	12. DATE OF FIRST SUBMISSION
LT	A	MTHLY	See Blk 16
8. APP CODE		**11. AS OF DATE**	**13. DATE OF SUBSEQUENT SUBMISSION**
			See Blk 16

16. REMARKS

Contractor format is authorized.

Blk 4 - Tailor DI-MGMT-80227 as follows: Delete paragraphs 10.3g, 10.3h, 10.3i, 10.3j, 10.3k, and 10.3n.

Blk 12 - The reporting period shall be from the first to last business day of each month. Initial submission shall be 60 DAC.

Blk 13 - Subsequent submissions shall be 10 days after the last business day of each month.

Distribution Statement A: Approved for public release, distribution is unlimited.

14. DISTRIBUTION

a. ADDRESSEE	b. COPIES		
	Draft	Final	
		Reg	Repro
MCLBA (837-1)	0	1	0
15. TOTAL →	0	1	0

17. PRICE GROUP	18. ESTIMATED TOTAL PRICE

G. PREPARED BY	H. DATE	I. APPROVED BY	J. DATE
[signature]	01/01/18	[signature]	01/18/01

CONTRACT DATA REQUIREMENTS LIST

(1 Data Item)

Form Approved
OMB No. 0704-0188

A. CONTRACT LINE ITEM NO.	B. EXHIBIT	C. CATEGORY: TDP ____ TM ____ OTHER X

D. SYSTEM/ITEM	E. CONTRACT/PR NO.	F. CONTRACTOR
Laundry Facility		

1. DATA ITEM NO.	2. TITLE OF DATA ITEM	3. SUBTITLE
B001	Inspection and Test Plan	Quality Control/Assurance and Inspection

4. AUTHORITY *(Data Acquisition Document No.)*	5. CONTRACT REFERENCE	6. REQUIRING OFFICE
DI-QCIC-81110	SOW 3.4	MCLBA (837)

7. DD 250 REQ	9. DIST STATEMENT REQUIRED	10. FREQUENCY	12. DATE OF FIRST SUBMISSION
DD	A	ONE/R	See Blk 16
8. APP CODE		**11. AS OF DATE**	**13. DATE OF SUBSEQUENT SUBMISSION**
			See Blk 16

16. REMARKS

Blk 12: Submit plan within 30 calendar days after contract award. MCLBA will provide acceptance/nonacceptance within 30 days.

Blk 13: Submit within 15 days after receipt and incorporation of MCLBA (Code 837-1) comments. Review cycle will be repeated until repair facility receives approval from MCLBA (Code 837-1).

Distribution Statement A: Approved for public release, distribution is unlimited.

14. DISTRIBUTION

a. ADDRESSEE	b. COPIES		
	Draft	Final	
		Reg	Repro
MCLB (837-1)	0	1	0
15. TOTAL →	0	1	0

17. PRICE GROUP

18. ESTIMATED TOTAL PRICE

G. PREPARED BY	H. DATE	I. APPROVED BY	J. DATE
[signature]	01/18/01	[signature]	01/18/01

CONTRACT DATA REQUIREMENTS LIST

(1 Data Item)

Form Approved
OMB No. 0704-0188

A. CONTRACT LINE ITEM NO.	B. EXHIBIT	C. CATEGORY: TDP ____ TM ____ OTHER X

D. SYSTEM/ITEM	E. CONTRACT/PR NO.	F. CONTRACT
Laundry Facility		

1. DATA ITEM NO.	2. TITLE OF DATA ITEM	3. SUBTITLE
C001	Repairable Item Inspection Report	Integrated Logistics Support Standards

4. AUTHORITY *(Data Acquisition Document No.)*	5. CONTRACT REFERENCE	6. REQUIRING OFFICE
DI-ILSS-80386	SOW 4.1	MLCBA (837)

7. DD 250 REQ	8. DIST STATEMENT REQUIRED	10. FREQUENCY	12. DATE OF FIRST SUBMISSION
LT	A	ASREQ	See Blk 16
8. APP CODE		**11. AS OF DATE**	**13. DATE OF SUBSEQUENT SUBMISSION**
			See Blk 16

16. REMARKS

Contractor format is authorized.

Blk 10 - A separate report shall be submitted for each Laundry Facility repaired.

Blks 12 & 13 - Submit report by Marine Corps Serial Number 30 days after completion of each Laundry Facility.

Blk 14 - Reports shall be provided on hard copy.

Distribution Statement A: Approved for public release, distribution is unlimited.

14. DISTRIBUTION

a. ADDRESSEE	b. COPIES		
	Draft	Final	
		Reg	Repro
MCLBA (837-1)	0	1	0
15. TOTAL →	0	1	0

17. PRICE GROUP

18. ESTIMATED TOTAL PRICE

G. PREPARED BY	H. DATE	I. APPROVED BY	J. DATE
		Gerald R Hall	01/18/01

DD FORM 1423-1, AUG 96 (EG) PREVIOUS EDITION MAY BE USED.

Designed using Perform Pro, WHS/DIOR, Aug 96

CONTRACT DATA REQUIREMENTS LIST

(1 Data Item)

Form Approved
OMB No. 0704-0188

A. CONTRACT LINE ITEM NO.	B. EXHIBIT	C. CATEGORY: TDP _____ TM _____ OTHER X

D. SYSTEM/ITEM	E. CONTRACT/PR NO.	F. CONTRACT
Laundry Facility		

1. DATA ITEM NO.	2. TITLE OF DATA ITEM	3. SUBTITLE
D001	Request For Deviation	Configuration Management

4. AUTHORITY *(Data Acquisition Document No.)*	5. CONTRACT REFERENCE	6. REQUIRING OFFICE
DI-CMAN-80640 C	SOW 3.3.2	MCLBA (851)

7. DD 250 REQ	8. DIST STATEMENT REQUIRED	10. FREQUENCY	12. DATE OF FIRST SUBMISSION
LT	A	ASREQ	SEE BLK 16
8. APP CODE		**11. AS OF DATE**	**13. DATE OF SUBSEQUENT SUBMISSION**

17. PRICE GROUP

18. ESTIMATED TOTAL PRICE

16. REMARKS

Blk 4 - Contractor format is authorized.

Blks 10 & 12 - RFDs shall be submitted to obtain authorization to deliver nonconforming material which does not meet prescribed configuration documentation.

RFDs will be reviewed and disposition determined within 30 calendar days upon receipt by the Government.

RFDs shall be submitted via e-mail to the following address: mbmatcomconfigmngmnt@matcom.usmc.mil

Distribution Statement A: Approved for public release, distribution is unlimited

14. DISTRIBUTION

a. ADDRESSEE	b. COPIES		
	Draft	Final	
		Reg	Repro
MCLBA (851-2)	0	1	0
15. TOTAL →	0	1	0

G. PREPARED BY	H. DATE	I. APPROVED BY	J. DATE
Carl Pitts	9-25-01	Gerald K Hall	01/18/01

DD FORM 1423-1, AUG 96 (EG) PREVIOUS EDITION MAY BE USED. Page ____ of ____ Pages

Designed using Perform Pro, WHS/DIOR, Aug 96